




Installation and Operational Manual

for safety please read this manual carefully keep it for future reference

THE ASSEMBLY OF WALKER


Included Item



1.24


WHEEL INSTALLATION


1




Step 1: Insert 4 wheels at the grooves on the back side of the base frame. Ensure the seal of wheel touches the frame. If the wheel is too tight, use hair blower to blow some hot air on the groove and then insert the wheel.

HOW TO UNFOLD







OPEN WALKER SEAT




Step 4: After the legs are fully open, rotate the seat and you will hear a click sound once it gets locked




at it position.



OPEN WALKER SEAT




Step 4: After the legs are fully open, rotate the seat and you will hear a click sound once it gets locked at it position.




INSTALL BACK REST

Step 5: Place the back rest and place the seat cushion over it.




INSTALL SEAT COVER

Step 6: Place the seat cover over the back rest and place all locks in respective grooves.




÷

INSTALL REAR BAR



INSTALL TOY BAR











Scan for Installation video

🕐 +91-9872399399 🛛 🔀 care@staranddaisy.in

www.staranddaisy.in